


FIG.1







FIG.3




FIG.4A

CAMERA MAIN BODY

(PREDETERMINED CYCLE)

S1

TRANSMIT USE STATUSES CORRESPONDING TO TIME ELAPSING BETWEEN PREVIOUS COMMUNICATION AND PRESENT COMMUNICATION

S2

RECEIVE CUMULATIVE USE STATUS VALUE, CONSUMED BATTERY CAPACITY AND CHARGE CAPACITY

S3

CALCULATE BATTERY USE QUANTITY

S4

BATTERY INFORMATION DISPLAY REQUEST ISSUED?

S5

YES  
DISPLAY BATTERY USE QUANTITY AND CAMERA USE STATUS

END

FIG.4B

BATTERY UNIT

S11

RECEIVE USE STATUSES

S12

ADD VALUE INDICATING MOST RECENTLY RECEIVED USE STATUS TO CUMULATIVE VALUE CALCULATED AT PREVIOUS COMMUNICATION AND STORE SUM

S13

CALCULATE CONSUMED BATTERY CAPACITY, ADD TO CUMULATIVE VALUE CALCULATED AT PREVIOUS COMMUNICATION AND STORE SUM

S14

TRANSMIT CUMULATIVE VALUE INDICATING PRESENT USE STATUS, CONSUMED BATTERY CAPACITY AND CHARGE CAPACITY

END

FIG. 5




FIG. 6




FIG.7A




FIG.7B




FIG. 8






FIG.9





FIG.10



11/15  
FIG.11




FIG.12




FIG.13




FIG.14




FIG.15

NO.	PHOTOGRAPHING CONDITION				NUMBER OF IMAGES THAT CAN BE PHOTOGRAPHED
	AF MODE	DISPLAY MONITOR	LIGHT EMITTING ILLUMINATION	ZOOM USE	
1	CONTINUOUS	ON	USED	USED	5
2	CONTINUOUS	ON	USED	NOT USED	6
3	SINGLE	ON	USED	USED	6
4	CONTINUOUS	ON	NOT USED	USED	7
5	SINGLE	ON	USED	NOT USED	7
6	CONTINUOUS	ON	NOT USED	NOT USED	8
7	CONTINUOUS	OFF	USED	USED	8
8	CONTINUOUS	OFF	USED	NOT USED	9
9	SINGLE	ON	NOT USED	USED	9
10	SINGLE	OFF	USED	USED	9
11	CONTINUOUS	OFF	NOT USED	USED	10
12	SINGLE	ON	NOT USED	NOT USED	10
13	SINGLE	OFF	USED	NOT USED	10
14	CONTINUOUS	OFF	NOT USED	NOT USED	11
15	SINGLE	OFF	NOT USED	USED	12
16	SINGLE	OFF	NOT USED	NOT USED	13